

FROLI®_Star Assembly Instructions



Dear Customer,

We thank you for choosing this FROLI brand product.

Please follow the instructions below to ensure correct assembly and use. For additional questions, please contact your authorized FROLI representative.

We hope that you will enjoy this product and we wish you many nights of healthy, recuperative sleep.

IMPORTANT! READ THESE INSTRUCTIONS BEFORE ASSEMBLY

Assembly


FROLI Star may be clipped together using a narrow, medium, or wide distance spacing by selecting the appropriate hole connection on the base element. This feature provides for firmness adjustments in accordance to body weight and personal preference.

The narrow spacing is recommended for a body weight in excess of 90 kg/ 200 lbs.

Hint: Vary the distance spacing lengthwise to create a "His and Hers" side.

Step 1


1. Lay out the base elements on the bed base, usually forming rows across, starting at the head end of the bed.
Hint: The arrow (triangle) mark embossed on each base element helps keep the elements lined up in a uniform fashion.
2. Choose a narrow, medium, or wide hole spacing, keeping in mind that the wider the setting, the softer the feel.
Hint: Use the wide spacing in the leg/feet region to maximize coverage.



3. First, arrange the base elements loosely on the surface with the locking holes resting on the clips, but do not connect them firmly, yet.




4. Then, connect the base elements at the desired position by pressing down firmly from the top to set the locking clip securely into the hole of the top element. Please use the assembly tool provided for this purpose.
Note: Never use a hammer for this procedure.



Step 2

1. After assembling the base elements to form a mat, fit a spring element with the slot to the center of each base element.
Hint: For convenient storage access under the bed, separate the mat into smaller sections and place them side by side.
2. Turn the spring element through 90 degrees so that the slot engages in the button of the base element.
3. The light blue (soft) springs are recommended for use in the shoulder area (3rd and 4th row from the top).
4. Unused parts of the base elements may be cut off along the bed sides to achieve a close custom fit.
If necessary, a "corner" of a spring element may be trimmed off for a close fit along a curved or irregular side. The spring will remain fully functional as long as three of its vertical supports remain intact.



Step 3

The tension clips provided in the package increase lumbar support when added to the center of the springs in the lower back region. They increase the firmness of the spring and may be added at a later time as required.

Simply hook the four ends of the tension clip into the inner ends of the spring element until they are firmly engaged.

